# ZE9000/ZE9000 PLUS   Installation Guide

1.Installation

Double-click WiLink.exe to start installation.

Note : If you have installed old version, please remove old one first.

Follow the instruction and continue the installation.

2.UI Description

"Ⅹ" - **Will close the program**

"—" - Zoom out to taskbar

"Gear" - Setting

You can also right-click wilink in the Windows taskbar to edit the **settings**

Channel：Will be selected automatically

Device ID：SSID can be defined, no less than 4 characters

Hidden_Form：**The default is hidden, the first time you open it, you need to show it**

3.Check ZE9000 SSID

The SSID on the product **label** or check the **ZE9000's WIFI SSID**

The SSID code for the example above is MediaServer**2037**

※**No need to connect ZE9000 from wifi list, Wilink will connect**

4. WiFi connection:

please click the edit icon [edit icon] to enter the SSID and click the icon again when you finish it.

※Please note that you don't have to type "DIRECT-" again.

When the status shows **OK**, the projection will autostart.

Trouble Shooting

A. Update Driver

If you have installed old version, please remove old one first.

Select **Start** [windows icon] , then select **Settings** > **Apps** > **Apps & features**.

Search "WiLink" and then select Uninstall.

B. Installation failed

If the following message appears during the installation.

Uninstall the driver and download Microsoft visual c++.

(Both x86 and x64 are required)

SMIUSBDisplaySW_v2.1.30.404.exe - System Error ✕

❌ The program can't start because MSVCP140.dll is missing from your computer. Try reinstalling the program to fix this problem.

OK

SMIUSBDisplaySW_v2.1.30.404.exe - System Error ✕

❌ The program can't start because VCRUNTIME140.dll is missing from your computer. Try reinstalling the program to fix this problem.blem.

OK

Download here:

VC_redist.x86.exe

https://aka.ms/vs/16/release/vc_redist.x86.exe

VC_redist.x64.exe

https://aka.ms/vs/16/release/vc_redist.x64.exe